


**TOOL SUPPORT CLAMP**

This type of wrist is generally used for corner tools; it allows for rigid clamping of the tool. The wrist is available in four sizes, depending on the vertical rod in use.




**6 HOLES**

WRIST MODEL	TORQUE LIMIT	AVAILABLE ACCESSORY FOR EACH ARM	NUMBER OF FLANGE HOLES	VERTICAL ROD	WEIGHT
	Nm	Size			
<b>MSO310000</b>	150	1	6	30X30	*
<b>MSO410000</b>	500	2-3	6	40X40	*
<b>MSO510000</b>	1000	3-5	6	50X50	*
<b>MSO610000</b>	2000	5	6	60X60	*

\* The WEIGHT varies depending on the size of the toolutilizzare.

**TOOL SUPPORT BRACKET**

This type of wrist is used for horizontal tightening using straight or pistola tools.



**6 HOLES**

WRIST MODEL	TORQUE LIMIT	AVAILABLE ACCESSORY FOR EACH ARM	NUMBER OF FLANGE HOLES	VERTICAL ROD	WEIGHT
	Nm	Size			
<b>SSO310000</b>	150	1	6	30X30	*
<b>SSO410000</b>	500	2-3	6	40X40	*
<b>SSO510000</b>	1000	3-5	6	50X50	*
<b>SSO610000</b>	2000	5	6	60X60	*

\* The WEIGHT varies depending on the size of the toolutilizzare.